

KYUDO | feeding replacement




1. Unplug the appliance from the power socket before start



2. Remove the label. Unscrew the "A" screw.



3.Remove the cover.



Control gear    Junction box    Cable clamp




4. Unscrew the screw to unlock the cable.




5. Cut the cable.




6. Unglow the control gear and remove it.



7. Separate the twin lamp's cable and strip it.



8. Open the junction box and connect the lamp's cables



9. Close the junction box and do the actions from 4 to 1 to close the lamp.